



Application:
Nissan Cube

Tools:
Phillips-head screwdriver and possibly a razor knife.

Location of cabin filter:

On the passenger side of the vehicle behind the glove compartment behind the cabin filter access panel.



To remove existing filter:

1. With glove box closed remove the two screws at the bottom and each end of the glove box. **(Figure 1)**. If this is first time replaced, you may need to use the razor knife and cut zip ties at the bottom of the glove box where you removed the screws. **(Figure 2)**. If you do not have the zip ties just move to the next step.
2. Open the glove box and remove the four screws securing the top of the glove box. **(Figure 3)**. Also remove the two screws inside the glove box toward the bottom. **(Figure 4)**.
3. Remove complete glove box assembly. **(Figure 5)**.
4. In the void left by the glove box assembly, look towards the center console and locate the cabin filter housing cover. Unlatch and remove the cover. **(Figure 6)**.
5. Remove the dirty filter.
6. Install new filter.
7. Re-install the cabin filter cover and make sure it is secure.
8. Reposition the glove box assembly.
9. With glove box open, re-install the four screws at the top and the two screws inside the glove box toward the bottom.
10. Close the glove box and re-install the two screws at the bottom of the glove box.



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6



Aplicación:

Nissan Cube, Juke

Herramientas:

Destornillador

Ubicación del filtro de cabina:

Detrás de la caja de guante.

Para quitar el filtro existente:

1. Quite los tornillos que sostienen la caja de guante en el luga. Véase el **cuadro 1**.
2. Quite la cubierta de la cubierta del aire de la cabina y quite el filtro de aire de la cabina. Véase el **cuadro 2**.
3. Sustituir el filtro de aire de la cabina por nuevo.
4. Invierta el procedimiento una vez que el nuevo filro está instalado.

Application :

Nissan Cube, Juke

Outils :

Tournevis

Endroit de filtre de carlingue :

Derrière la boîte à gants.

Pour enlever le filtre existant :

1. Enlevez les vis tenant la boîte à gants en place. Voir le **schéma 1**.
2. Enlevez la couverture du logement d'air de carlingue et enlevez le filtre á air de carlingue. Voir le **schéma 2**.
3. Remplacer le filtre à air de carlingue par le neuf.
4. Renversez le procédé une fois que le nouveau filtre est installé.