



Application:
Ford Mustang

Tools:
Unknown or not required.

Location of cabin filter:
Passenger side of the vehicle under the glove box.

To remove existing filter:

1. Remove the retainers and the RH lower instrument panel insulator. See **Figure 1**.
2. Remove the retainer and the cabin air filter cover. See **Figure 2**.
3. Remove the cabin air filter. See **Figure 3**.

Installation:

1. Reverse the removal procedure.



Figure 1




Figure 2




Figure 3



Aplicación:

Ford Mustang

Herramientas:

Desconocidas, o no se requieren.

Ubicación del filtro para la cabina:

Lado del pasajero del vehículo, debajo de la guantera.

Para retirar el filtro existente:

1. Desmonte los retenes y el aislante del panel inferior de instrumentos del lado derecho. Consulte la **Figura 1**.
2. Desmonte el retén y la tapa del filtro de aire para la cabina. Consulte la **Figura 2**.
3. Retire el filtro de aire para la cabina. Consulte la **Figura 3**.

Instalación:

1. Invierta el procedimiento de desmontaje.

Application :

Ford Mustang

Outils :

Inconnu ou aucun nécessaire.

Emplacement du filtre d'habitacle :

Côté passager du véhicule sous la boîte à gants.

Pour déposer le filtre existant :

1. Déposez les axes de retenue et l'isolant du tableau de bord inférieur droit. Voir **Figure 1**.
2. Déposez l'axe de retenue et le couvercle du filtre à air d'habitacle. Voir **Figure 2**.
3. Déposez le filtre à air d'habitacle. Voir **Figure 3**.

Installation :

1. Appliquez la procédure de dépose dans le sens inverse.